



WIK346 Installation Kit

Thank you for purchasing the WIK346 Wiring Kit. We've designed it to make the 346 and similar pump installation as clean and easy as possible.

In the Kit:

- 30 AMP "Bosch Style" relay (Actual source manufacturer may vary)
- Harness w/ 20 AMP fuse
- 1 - 18-22ga. T-Tap
- 1 - 18-22ga. Male Spade Terminal
- 1 - 10-12ga. Ring Terminal
- 1 - 14-16ga. Ring Terminal
- 1 - 14-16ga. Butt connector
- 1 - 2.5" 3/16 heat shrink tubing

Wiring for Ford Modular applications:

- Orange wire #30 to backside of alternator at 12 volt post
- Black #85 to ground
- Blue wire #87 to fused blue wire to water pump
- Green #86 to "key on" source (found inside fuse panel)
- Or to fuel injector trigger wire at the injector

Wiring for all other applications:

- Orange wire #30 to positive battery post or 12 volt source
- Black #85 to ground
- Blue wire #87 to fused blue wire to water pump
- Green #86 to "key on" source

