



WP127 AMC 360-401 Timing Cover Back Plate

This back plate is used with our WP111 Small Block Ford Water Pump sold separately

This pump and back plate will not work with the factory accessory brackets you will need to make custom or modify the factory brackets. Meziere does not offer accessory brackets.

In The Box You Will Find:

- 1 Timing Cover Back Plate
- 1 3/8 – 16 x 4 1/2” SS bolt
- 3 3/8-16 x 4” SS bolt
- 3 5/16-18 x 3/4” SS bolt
- 7 1/4-20 x 3/4” SS bolt
- 1 10-24 x 3/8” SS set screw
- 3 5/16 AN washers

To Do The Job You Will Need:

- AMC water pump gasket to match your front cover
- Scraper or wire brush
- Brake cleaner
- Sealant; Form A Gasket (Aviation), Form A Gasket 2 (Non-Hardening), Gaskacinch or RTV silicone
- Thread sealant; RTV silicone or liquid pipe thread sealant
- Hex head socket or wrenches
- 3/8” drill bit and drill

Mounting The Back Plate

Remove stock water pump, clean and degrease the gasket surface. Apply sealant to both sides of factory gasket and tack to the backside of the Meziere back plate, align gasket to bolt holes and bolt to timing cover using supplied hardware

Mounting Pump

You may need to drill the lower driver side mounting hole on the pump to 3/8”. You will need to check your factory front cover to see what size bolt it uses for this hole.